

A Level Physics A

H556/02 Exploring physics

Question Set 17

- 1 (a) An approximate value of the Planck constant h can be determined in the laboratory using light-emitting diodes (LEDs). An LED suddenly starts to conduct and emit monochromatic light when the potential difference across an LED exceeds a minimum value V_0 . The potential difference V_0 and the wavelength λ of the emitted light are related by the equation

$$V_0 = \left(\frac{hc}{e}\right) \times \frac{1}{\lambda}$$

where e is the elementary charge and c is the speed of light in a vacuum.

Fig. 20.1 shows some data points plotted by a student on a V_0 against $\frac{1}{\lambda}$ graph for five different LEDs.




Fig. 20.1

The potential difference across each LED was measured using a digital voltmeter with divisions ± 0.01 V. The values for the wavelengths are accurate and were provided by the manufacturer of the LEDs.

The value of V_0 was determined by directly observing the state of the LED in the **brightly** lit laboratory.

- (i) Draw the straight line of best fit on Fig 20.1 and determine the gradient of the line.

gradient = V m [2]

- (ii) Use your answer in (i) and the equation on the page above to determine a value for h to 2 significant figures. Show your working.

$$h = \dots\dots\dots \text{Js} \quad [3]$$

- (iii) Calculate the percentage difference between your value in (ii) and the accepted value of the Planck constant.

$$\text{difference} = \dots\dots\dots \% \quad [1]$$

- (iv) Identify the two types of errors shown by the data in Fig. 20.1 and suggest how you could have refined the experiment to reduce or eliminate these errors.

[4]

- (b) Fig. 20.2 shows a gold-leaf electroscope with a clean zinc plate.




Fig. 20.2

The zinc plate, metal stem and the gold-leaf are given a negative charge by briefly connecting the zinc plate to the negative electrode of a high-voltage supply.

The gold leaf is fully diverged.

The position of the leaf is not affected by intense white light from a table lamp incident on the zinc plate. The gold leaf collapses very quickly when low-intensity ultraviolet radiation from a mercury lamp is incident on the zinc plate.

Explain these observations in terms of photons.

[4]

Total Marks for Question Set 17: 14

OCR

Oxford Cambridge and RSA

Copyright Information

OCR is committed to seeking permission to reproduce all third-party content that it uses in its assessment materials. OCR has attempted to identify and contact all copyright holders whose work is used in this paper. To avoid the issue of disclosure of answer-related information to candidates, all copyright acknowledgements are reproduced in the OCR Copyright Acknowledgements Booklet. This is produced for each series of examinations and is freely available to download from our public website (www.ocr.org.uk) after the live examination series.

If OCR has unwittingly failed to correctly acknowledge or clear any third-party content in this assessment material, OCR will be happy to correct its mistake at the earliest possible opportunity.

For queries or further information please contact The OCR Copyright Team, The Triangle Building, Shaftesbury Road, Cambridge CB2 8EA.

OCR is part of the Cambridge Assessment Group; Cambridge Assessment is the brand name of University of Cambridge Local Examinations Syndicate (UCLES), which is itself a department of the University of Cambridge